

ALR Series Electronic Linear Actuators

+1 413 233 1888

www.governors-america.com

1 INTRODUCTION

The ALR Series Electronic Linear Integral Actuators are designed to mount directly to the engine's fuel pump in place of the electronic stop solenoids. The ALR Series high-quality construction is designed for high-temperature operation. GAC's unique linear electromechanical technology provides proportional actuator movement based on actuator coil current. GAC uses precision linear ball bearings instead of bushings giving the ALR Series a minimum number of moving parts, improving response, precision and reliability.

The ALR Series Actuator is designed to replace the OEM equipped shut down solenoid. To properly install the ALR actuator, a precise measurement must be obtained from the removed OEM equipped shutdown solenoid. Before beginning the installation of the ALR actuator, remove all DC battery power from the equipment being serviced.

Section 2 lists the common engine models ALRs are used with. See your GAC representative for other makes and models.



2 APPLICATIONS - ALL MODELS

NOTE Check engine dimensions before selecting or installing an ALR as alterations made to factory engines may impact ALR fit.

ENGINE FAMILY	ENGINE MODEL	ACTUATOR MODEL
CATERPILLAR		
C Series	C2.2T	ALR190-P04 -12 or -24
	C3.4	
	C1.5	ALR160-S04 -12 or -24
	C0.5	ALR160-M-12
PERKINS		
Perkins	404D-15 404D-22	ALR190-P04 -12 or -24 or ALR160-S04 -12 or -24
SHIBAURA (PERKINS)		
Shibaura (Perkins)	N843-C, N844L-C, N844LT-C	ALR160-S04 -12 or -24 ALR190-P04 -12 or -24

ENGINE FAMILY	ENGINE MODEL	ACTUATOR MODEL
ISUZU		
C-Series	2CA 3CA 3CB 3CD 3CE	ALR190-Y04 -12 or -24
L-Series	3LB1 3LD1 3LD2 4LE1 4LE2	ALR190-I03 -12 or -24
KUBOTA		
Super 5 Series	D905	ALR190-K04 -12 or -24
	D1005	
	D1105	
	D1105-T	
	V1305	
	V1505, -T	
V3 Series	V3300 V3600 V3600T V3800	
03 Series	V2003 V2203* V2403	ALR190-KV03 -12 or -24
07 Series	V2607 V3007 V3307	ALR190-KV07 -12 or -24
DI-T	V3800DI-T	ALR190- KV03DIT -12 or -24

ENGINE FAMILY	ENGINE MODEL	ACTUATOR MODEL
MITSUBISHI		
L-Series	L2E	ALR190-M04 -12
	L3E	
S3L-Series	S3L	
	S3L2	
	S4L	
	S4L2	
YANMAR		
TNV- and TNE-Series	2TNV70	ALR190-Y04 -12 or -24
	3TNV70	
	3TNV76	
	3TNV82A	
	3TNV84	
	3TNV84T	
	3TNV88	
	4TNV84	
	4TNV94L	
	4TNV88	
	4TNV98	
	4TNV98T	
	2TNE	
	3TNE	
4TNE		



* IDI model only

3


ELECTRICAL		
	190-I, 190-K, 190-M, 190-P, 190-Y	160-S
Operating Voltage	12 or 24 V DC	12 or 24 V DC
Normal Operating Current	3.2 A @12 V DC 1.6 A @24 V DC	4.8 A @12 V DC 2.4 A @24 V DC
Maximum Current Continuously Rated	5.0 A @12 V DC 2.5 A @24 V DC	7.5 A @12 V DC 3.8 A @24 V DC
Coil Resistance (12 V DC) (24 V DC)	1.8 ± 0.2 Ω 6.3 ± 0.2 Ω	1.5 ± 0.1 Ω 6.0 ± 0.2 Ω
Connection 16 AWG	(0.8 mm ²) leads	(0.8 mm ²) leads
ENVIRONMENTAL		
Operating Temperature Range	-40 to +200 °F [-40 to 95 °C]	
Relative Humidity	up to 100 %	
Vibration	± 4 g, 25 to 100 Hz	
Shock	20 g Peak, 11 ms	
All Surface Finishes	Fungus Proof and Corrosion Resistant	
Sealing	Oil, Water, and Dust Resistant	

PERFORMANCE		
MODEL	OPERATING STROKE	RESPONSE TIME (1 - 90 %)
160-S	0.51 in (13.0 mm)	1-12 mm 35 ms
190-I	0.55 in (14.0 mm)	2-12.6 mm 35 ms
190-K	0.49 in (12.5 mm)	1-12 mm 35 ms
190-M	0.54 in (13.9 mm)	1-13 mm 35 ms
190-P	0.42 in (10.4 mm)	1-9 mm 35 ms
190-Y	0.34 in (9.0 mm)	1-8 mm 35 ms


Hardware	
Connector Type	Models
Spade	ALR190-I03
Packard	ALR160-S04, ALR190-I03, ALR190-K04, ALR190-KV03, ALR190-KV07, ALR190-KV03DIT, ALR190-M04, ALR190-P04, ALR190-Y04
Physical	
Weight	1.3 lbf [0.59 kgf]

4

ALR160-S




ALR190-P04




Dimensions: [mm]
in

ALR190-I




Dimensions: [mm]
in


ALR190-M




ALR190-Y04




ALR190-K04



ALR190-KV03



ALR190-KV03DIT, ALR190-KV07





1. The engine should be equipped with an independent shut down device to prevent overspeed, which can cause equipment damage or personal injury.
2. Do not attempt this installation with engine running or serious damage may occur to the equipment or personnel.
3. **Before beginning the ALR installation, remove all DC battery power from the equipment being serviced.**

NOTE

The ALR190-M04 is the only actuator that includes shims.

INSTALLATION PROCEDURE FOR ALR190-M04


The ALR190-M unit must be adjusted for proper operation.

If the installation procedure is not followed, damage to the actuator and or injection pump is possible.

1. Index mark the OEM shutdown solenoid directly behind the locknut with a marker or scribe before loosening the locknut. This mark is important. A precise measurement (depth micrometer) will be taken after shutdown solenoid is removed from the injection pump housing.
2. Remove the wiring harness and loosen the solenoid locknut. Clean the area from dirt or grease. Loosen and remove solenoid from the injection pump housing using standard service cautions.
3. Move locknut on shutdown solenoid back to previously indexed mark (Step 1) and measure distance from the front side of locknut (side that was previously against injection pump housing) to the end of shutdown solenoid shaft. Record this measurement. The more precise this measurement (depth micrometer) the more precise the ALR actuator will perform.
4. Use the locknut from the old shut off solenoid and position it on the new ALR actuator the same distance as the old solenoid (Step 2). *Shims are included with this actuator if needed to set position.
5. Clean threads and mounting surface of the ALR actuator. Install ALR into injection pump housing (no sealant required) until locknut is flush with injection pump housing. If resistance is felt, remove ALR and inspect threads for dirt or burrs. Also use a clean lint free rag to clean injection pump internal threads. A small amount of clean engine oil can be applied if desired. When locknut is flush with injection pump housing tighten nut down.
6. Install wiring harness, start engine, adjust governor speed controller following the GAC manual.

STEP 2

Use locknut from old shutoff actuator and position the locknut on the new actuator at the same distance as "X".

**STEP 1**

With the locknut in the exact same position as it was installed in the pump, measure and record this dimension.

The more precise the measurement the more precise the ALR actuator will perform. Use this dimension to set the position of the ALR actuator.

5 INSTALLATION (CONTINUED)

INSTALLATION PROCEDURE FOR ALR190-I, 190-P, AND ALR160-S

1. The actuator is installed in place of the engine's stop solenoid. Remove the solenoid by first disconnecting the electrical leads at the connector.
2. Remove the wiring harness and loosen the solenoid locknut. Clean the area from dirt or grease. Loosen and remove solenoid from the injection pump housing using standard service cautions.
3. Discard OEM installed shutdown solenoid and locknut. Locknut is NOT REQUIRED for the ALR installation.
4. Clean threads and mounting surface of the ALR actuator. Install ALR into injection pump housing (no sealant required) until actuator package is flush with injection pump housing.
 - If resistance is felt, remove ALR and inspect threads for dirt or burrs. Use a clean lint free rag to clean injection pump internal threads. A small amount of clean engine oil can be applied if desired.
 - When actuator is flush with injection pump housing, hand tighten only. After engine has reached operating temperature recheck tightness (use caution, unit will get hot), if required re-tighten by hand only.
5. Install wiring harness, start engine, adjust governor speed controller following the GAC manual.

INSTALLATION PROCEDURE FOR 190-K AND 190-Y

1. The actuator is installed in place of the engine's stop solenoid. Remove the solenoid by first disconnecting the electrical leads at the connector.
2. Cover and secure the engine harness leads as they are no longer needed.
3. Remove the two screws that attach the solenoid to the pump face. Save the screws and O-ring. They will be reused when attaching the actuator.
4. Install the o-ring into the counter bore on the pump face.
5. Install the actuator using the solenoid screws.
6. Attach the actuator leads from the speed control unit.

6 TROUBLESHOOTING

TROUBLE SHOOTING

If the actuator fails to move to full fuel, complete the following tests:

1. Measure battery voltage at the controller (see specification for the operating voltage).
2. Check linkage. Manually operate linkage to ensure it is not sticking or binding.

If the actuator fails to move, make the following tests:

1. Measure the coil resistance between the actuator leads (see specification for resistance).
2. Measure the resistance between one lead of the actuator and the housing of the actuator. It should be infinity.
3. Energize the actuator to full fuel by following the procedure in the control unit publication. If the actuator does not move, it is defective.

If problems occur, contact your GAC representative or GAC at www.governors-america.com